



Drawing **035-A**

Description **Fixed hexagonal Valve**

ASSEMBLY INSTRUCTION:

Insert the item into the radiator connector and rotate it until the O-ring is adherent to the outside surface of the connector.

Make sure that the O-ring adheres to the flat surface of the connector and is not ejected from the seat.

Even if the valve can withstand a tightening torque of 10 Nm, do not exceed the maximum recommended tightening torque of 8 Nm to prevent the O-ring from being ejected from the seat, cut or permanently deformed.

The connected part must comply with DIN 76-2

The installer is responsible for checking that the component is installed correctly by bringing the system at least up to the operating pressure and ensuring that no leaks occur.

Freezing of the fluid inside the system must be absolutely avoided to prevent the breakage of the component, which is not designed to withstand the overpressure caused by the change of state.

COMPONENTS:

BODY AND SCREW:BRASS UNI EN 12164 CW614N

NICKEL-PLATING 3-5 MICRON

ORING EPDM 70 SH BLACK

TECHNICAL NOTES:

BODY:TIGHTENING TORQUE MAX= 10 NM

SCREW:TIGHTENING TORQUE FROM 0,8 TO 2 NM

UTILIZATION TEMPERATURE=80°C PEAK=130°C

UTILIZATION PRESSURE=10BAR PEAK=13BAR