



Drawing **0036**

Description **Hexagonal Valve with Teflon Oring**

ASSEMBLY INSTRUCTION:

Insert the item into the radiator connector and rotate it until the gasket is adherent to the outside surface of the connector.

Make sure that the gasket is not ejected from the seat.

Even if the plug can withstand a tightening torque of 15 Nm, do not exceed the maximum recommended tightening torque of 10 Nm to prevent the gasket from being ejected from the seat, cut or permanently deformed.

The connected part must comply with DIN 76-2

The installer is responsible for checking that the component is installed correctly by bringing the system at least up to the operating pressure and ensuring that no leaks occur.

Freezing of the fluid inside the system must be absolutely avoided to prevent the breakage of the component, which is not designed to withstand the overpressure caused by the change of state.

COMPONENTS:

BODY: BRASS UNI EN 12164 NICKEL-PLATING

SCREW: NYLON 6 WHITE

GASKET: TEFLON

TECHNICAL NOTES:

BODY TIGHTENING TORQUE MAX=15NM

SCREW TIGHTENING TORQUE= MAX 0,8 NM

UTILIZATION TEMPERATURE=80°C PEAK=110°C

UTILIZATION PRESSURE=4BAR PEAK=10BAR



Drawing **0037**

Description **Hexagonal Valve with Teflon Oring**

ASSEMBLY INSTRUCTION:

Insert the item into the radiator connector and rotate it until the gasket is adherent to the outside surface of the connector.

Make sure that the gasket is not ejected from the seat.

Even if the plug can withstand a tightening torque of 10 Nm, do not exceed the maximum recommended tightening torque of 8 Nm to prevent the gasket from being ejected from the seat, cut or permanently deformed.

The connected part must comply with DIN 76-2

The installer is responsible for checking that the component is installed correctly by bringing the system at least up to the operating pressure and ensuring that no leaks occur.

Freezing of the fluid inside the system must be absolutely avoided to prevent the breakage of the component, which is not designed to withstand the overpressure caused by the change of state.

COMPONENTS:

BODY: BRASS UNI EN 12164 NICKEL-PLATING

SCREW: NYLON 6 WHITE

GASKET: TEFLON

TECHNICAL NOTES:

BODY TIGHTENING TORQUE MAX=10NM

SCREW TIGHTENING TORQUE MAX=0,8 NM

UTILIZATION TEMPERATURE=80°C PEAK=110°C

UTILIZATION PRESSURE=4BAR PEAK=10BAR



Drawing **0038**

Description **Hexagonal Valve with Teflon Oring**

ASSEMBLY INSTRUCTION:

Insert the item into the radiator connector and rotate it until the gasket is adherent to the outside surface of the connector.

Make sure that the gasket is not ejected from the seat.

Even if the plug can withstand a tightening torque of 35 Nm, do not exceed the maximum recommended tightening torque of 10 Nm to prevent the gasket from being ejected from the seat, cut or permanently deformed.

The connected part must comply with DIN 76-2

The installer is responsible for checking that the component is installed correctly by bringing the system at least up to the operating pressure and ensuring that no leaks occur.

Freezing of the fluid inside the system must be absolutely avoided to prevent the breakage of the component, which is not designed to withstand the overpressure caused by the change of state.

COMPONENTS:

BODY: BRASS UNI EN 12164 NICKEL-PLATING

SCREW: NYLON 6

WHITE GASKET: TEFLON

TECHNICAL NOTES:

BODY TIGHTENING TORQUE MAX=35NM

SCREW TIGHTENING TORQUE MAX=0,8 NM

UTILIZATION TEMPERATURE=80°C PEAK=110°C

UTILIZATION PRESSURE=4BAR PEAK=10 BAR